Table of Contents

1. nRF52840 Zephyr BLE client 2
1.1. BLE Health Temperature peripheral 2

1. nRF52840 Zephyr BLE client

Usually, the BLE client role plays some user device eg. mobile phone, tablet or computer. In IoT systems sometimes BLE is used for M2M (machine-to-machine) data transmission. In such a situation an automatic BLE client must be implemented to connect to the peripherals and read the data eg. coming from BLE-capable sensors. BLE client must be configured to connect to the peripheral which exposes some specific service and characteristic. To do the lab exercise there is a need to create the peripheral device first.

1.1. BLE Health Temperature peripheral

From:
https://dokuwiki.zmitac.aei.polsl.pl/ - **RAU6 Dokuwiki**

Permanent link:
https://dokuwiki.zmitac.aei.polsl.pl/en:edu:zmitac:s2:aih:lab:nrf52zephyrblecentral?rev=1703016935

Last update: **2023/12/19 21:15**